

Specifications

| | |
|-------------------------|--------------------------------|
| Item | - 35686B |
| Model | - LED8T8/835/2FT/HYBRID/SS/G3 |
| Bulb Type | - LED T8 |
| Base | - G13 |
| Watts | - 8 Watts |
| Input Voltage | - 120-277VAC 50/60Hz |
| UL Rating | - Dry/Damp Location |
| Dimmable | - No |
| Length | - 23.69 inches (602mm) |
| Kelvin Color | - 3500 |
| Beam Angle | - 180° |
| Lumens | - 1000 |
| Average Life Hours | - 50,000 |
| Ambient Operating Temp. | - -40°F ~ 104°F (-40°C ~ 40°C) |



Caution

- This UL Type A+B hybrid must be wired in accordance with the National Electrical Code (NEC) and applicable local ordinance. Proper grounding is required to ensure personal safety. Carefully observe grounding procedure under the installation section.
- Make certain power is OFF before starting the installation or attempting any maintenance. Risk of fire/electric shock. If not qualified, consult a licensed electrician.
- Disconnect power at fuse or circuit breaker before installing or servicing.
- RISK OF BURN - Disconnect power and allow the bulb to cool before servicing.
- RISK OF PERSONAL INJURY - Bulb may become damaged and/or unstable if not installed properly. Make sure all fixture components are securely tightened.

Precaución

- Este accesorio debe estar conectado de acuerdo con el National Código Eléctrico (NEC) y ordenanzas locales aplicables. Apropiado Se requiere conexión a tierra para garantizar la seguridad personal. Cuidadosamente observe el procedimiento de conexión a tierra en la sección de instalación.
- Asegúrese de que la alimentación esté apagada antes de comenzar la instalación o intentando cualquier mantenimiento. Riesgo de incendio / descarga eléctrica. Si no calificado, consulte a un electricista con licencia.
- Desconecte la energía en el fusible o en el interruptor de circuito antes de instalar o servicio.
- RIESGO DE QUEMADURAS: desconecte la alimentación y permita que el dispositivo se enfríe antes de dar servicio
- RIESGO DE LESIONES PERSONALES: el accesorio puede dañarse y / o inestable si no se instala correctamente. Asegúrese de que todos los accesorios. Los componentes están bien apretados.

