



Specifications

Item	- 35693A
Model	- LED Exit Sign
Input Voltage	- 120/277VAC 60Hz
Listings	- UL Listed
Dimmable	- No
Height	- 7.2 inches (182mm)
Width	- 1.8 inches (46mm)
Length	- 11.6 inches (295mm)
Ambient operating temp.	- 32°F to 104°F (0°C to 40°C)
Housing	- Thermoplastic
Battery	- Ni-CD 1.2V 900MAH
Installation Type	- Wall or Ceiling
Battery Life	- ≥ 90 minutes

Caution

- Do not use outdoors
- Equipment should be mounted in locations and at heights where it will not be subject to tampering by unauthorized personnel.
- Do not mount near gas or electric heaters
- The use of accessory equipment that is not recommended by the manufacturer may cause an unsafe condition.
- Do not use this equipment for other than its intended use.
- Installation and servicing of this equipment should be performed by qualified personnel.
- Disconnect AC power before servicing
- Use caution when servicing batteries. Battery acid can cause burn to skin or eyes, If acid is spilled on skin or eyes flush acid with fresh water and contact a physician immediately.
- Suitable for indoor dry/damp locations

Precaución

- No usar al aire libre.
- El equipo debe montarse en ubicaciones y alturas donde no estará sujeto a manipulación por personas no autorizadas personal.
- No lo monte cerca de calentadores de gas o eléctricos.
- El uso de equipos accesorios que no se recomiendan por el fabricante puede causar una condición insegura
- No use este equipo para otro uso que no sea el previsto.
- La instalación y el mantenimiento de este equipo deben ser realizados por personal calificado.
- Desconecte la alimentación de CA antes de realizar el mantenimiento.
- Tenga precaución cuando repare las baterías. El ácido de la batería puede causar quemaduras a la piel u ojos, si se derrama ácido sobre la piel o los ojos, enjuague el ácido con agua y contacte a un médico inmediatamente.



NOTICE

The battery in this unit may not be fully charged after electricity is connected to the unit. Let the battery charge for at least 24 hours. To check the batteries function press the PUSH TO TEST switch, the light inside should turn on.

Unused wires must be capped using enclosed wire nuts.

During an electrical outage the lamps will automatically come on for a minimum of 90 minutes.

To test, press the "TEST" switch. This will interrupt the AC power and revert to battery power for testing. When released the unit will return to AC power mode.

All wiring must be done in accordance to National Electrical Code (NEC) and local codes. Proper grounding is required to ensure personal safety. Carefully observe grounding procedure under the installation section.

Ceiling and End Mount Installation

1. Connect input as shown in wiring diagram below and fasten canopy to the J-Box bracket.
2. Snap housing to canopy.
3. Connect the battery (when applicable) to the PC board.
4. Secure faceplate to housing and remove proper arrow as required.

Wiring Diagram

