



### Specifications

Item	- 35770A
Model	- LED36T8/8FT/65K/R17D/BP
Bulb Type	- LED Type B
Bulb Shape	- T8
Base Type	- R17D w/ Rotating Ends
Beam Angle	- 330° (Double Sided LED Strip)
Input Voltage	- 120-277VAC 50/60Hz
Watts	- 36
Diameter	- 1.14in (29mm)
Length	- 93.8in (2383mm)
Kelvin Color	- 6500
CRI	- >80
Power Factor	- >0.9
Lumens	- 5000
Dimmable	- No
Average Life Hours	- 50,000
Ambient Operating Temp	- -4°F ~ 113°F (-20°C ~ 45°C)

### Caution

- This fixture must be wired in accordance with the National Electrical Code (NEC) and applicable local ordinance. Proper grounding is required to ensure personal safety. Carefully observe grounding procedure under the installation section.
- Make certain power is OFF before starting the installation or attempting any maintenance. Risk of fire/electric shock. If not qualified, consult a licensed electrician.
- Disconnect power at fuse or circuit breaker before installing or servicing.
- RISK OF BURN - Disconnect power and allow the fixture to cool before servicing.
- RISK OF PERSONAL INJURY - Fixture may become damaged and/or unstable if not installed properly. Make sure all fixture components are securely tightened.

### Precaución

- Este accesorio debe estar conectado de acuerdo con el National Código Eléctrico (NEC) y ordenanzas locales aplicables. Apropiado Se requiere conexión a tierra para garantizar la seguridad personal. Cuidadosamente observe el procedimiento de conexión a tierra en la sección de instalación.
- Asegúrese de que la alimentación esté apagada antes de comenzar la instalación o intentando cualquier mantenimiento. Riesgo de incendio / descarga eléctrica. Si no calificado, consulte a un electricista con licencia.
- Desconecte la energía en el fusible o en el interruptor de circuito antes de instalar o servicio.
- RIESGO DE QUEMADURAS: desconecte la alimentación y permita que el dispositivo se enfríe antes de dar servicio
- RIESGO DE LESIONES PERSONALES: el accesorio puede dañarse y / o inestable si no se instala correctamente. Asegúrese de que todos los accesorios. Los componentes están bien apretados.



## Caution

**WARNING** - Risk of fire or electric shock. The electrical rating of these products is 120-277VAC, before installation determine if you have this voltage at the luminaire.

**WARNING** - Risk of fire or electric shock. LED Retrofit Kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.

**WARNING** - Risk of fire or electric shock. Install this kit only in luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

**WARNING** - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

**WARNING:** To avoid potential fire or shock hazard, do not use this retrofit kit in luminaires employing shunted bi-pin lampholders.

Note: Shunted lamp holders are found only in fluorescent luminaires with Instant-Start ballasts. Instant-start ballasts can be identified by the words "Instant Start" or "I.S." marked on the ballast. This designation may be in the form of a statement pertaining to the ballast itself, or may be combined with the marking for the lamps with which the ballast is intended to be used, for example F40T12/IS. For more information, contact the LED luminaire retrofit kit manufacturer.

Installers should not disconnect existing wires from lampholder terminals to make new connections at lampholder terminals. Instead installers should cut existing lampholder leads away from the lampholder and make new electrical connections to lampholder lead wires by employing applicable connectors.

THE RETROFIT KIT IS ACCEPTED AS A COMPONENT OF A LUMINAIRE WHERE THE SUITABILITY OF THE COMBINATION SHALL BE DETERMINED BY AUTHORITIES HAVING JURISDICTION. PRODUCT MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH THE APPLICABLE AND APPROPRIATE ELECTRICAL CODES. THE INSTALLATION GUIDE DOES NOT SUPERSEDE LOCAL OR NATIONAL REGULATIONS FOR ELECTRICAL INSTALLATIONS.

DO NOT USE WITH DIMMERS. - USE IN DRY OR DAMP LOCATIONS ONLY. - DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS

## Installation Instructions

1. Ensure power is disconnected and/or circuit breaker is off.
2. Remove existing diffuser (if applicable), fluorescent tube, and open the ballast cover. Dispose of fluorescent tube(s) according to local, state, or federal laws, [www.lamprecycle.org](http://www.lamprecycle.org).
3. Disconnect power supply wires L (line) and N (neutral) to the ballast and leads from the ballast to the fluorescent sockets as shown in Figure 1.
4. Connect line VAC to the lampholder non-shunted socket, L (line) to one lead, N (neutral) to other lead as shown in figure 2.
5. Attach modified luminaire sticker to a visually prominent area near the lamp sockets. Replace the ballast cover, insert LED tube(s), and diffuser (if applicable).
6. Turn on the power source and check for proper operation.

